

Roller Blinds System | RolloSystem | Système Rouleaux



Small - RS

Medium - RM

Large - RL

	Bracket	Fixing profile	Cassette round	Bracket	Fixing profile	Cassette round	Cassette angular	Cover flat Bracket	Cover flat fixing profile	Cover round Bracket	Cover round fixing profile	Bracket	Cassette round	Cassette angular	Cover flat fixing profile	Cover round fixing profile
	Halter	Trägerprofil	Kassette rund	Halter	Trägerprofil	Kassette rund	Kassette eckig	Blende flach Halter	Blende flach Trägerprofil	Blende rund Halter	Blende rund Trägerprofil	Halter	Kassette rund	Kassette eckig	Blende flach Trägerprofil	Blende rund Trägerprofil
	<i>Support</i>	<i>Profilé support</i>	<i>Coffre arrondi</i>	<i>Support</i>	<i>Profilé support</i>	<i>Coffre arrondi</i>	<i>Coffre carré</i>	<i>Cache plat Support</i>	<i>Cache plat profilé support</i>	<i>Cache arrondi Support</i>	<i>Cache arrondi profilé support</i>	<i>Support</i>	<i>Coffre arrondi</i>	<i>Coffre carré</i>	<i>Cache plat profilé support</i>	<i>Cache arrondi profilé support</i>

© 2012 Benthin® | Version 20-02-2012
Misprints, errors and changes excepted
Druckfehler, Irrtümer und Änderungen vorbehalten
Sous réserve de fautes d'impression, d'erreurs et de modifications.

max.	1,80 x 2,50 m	1,80 x 2,50 m	1,80 x 2,00 m	2,80 x 3,00 m	2,80 x 3,00 m	2,80 x 3,00 m	2,80 x 3,00 m	2,80 x 3,00 m	2,80 x 3,00 m	2,80 x 3,00 m	2,80 x 3,00 m	4,00 x 4,00 m	4,00 x 4,00 m	4,00 x 4,00 m	4,00 x 4,00 m	4,00 x 4,00 m
------	---------------	---------------	---------------	---------------	---------------	---------------	---------------	---------------	---------------	---------------	---------------	---------------	---------------	---------------	---------------	---------------

Operation Bedienung Manœuvre																		
		Chain Kette <i>Chaînette</i>	RS01	RS11	RS21	RM01	RM11	RM21	RM31	RM41	RM61	RM51	RM71	RL01	RL21	RL31	RL61	RL71
	Spring Mittelzug <i>Store automatique</i>	RS02	RS12	RS22	RM02	RM12	RM22	RM32	RM42	RM62	RM52	RM72						
	Cord Schnur <i>Cordon</i>	RS05	RS15															
	Motor Motor <i>Motor</i>			RS26	RM06	RM16	RM26	RM36	RM46	RM66	RM56	RM76	RL06	RL26	RL36	RL66	RL76	
	Crank Kurbel <i>Manivelle</i>				RM07	RM17	RM27		RM47	RM67	RM57	RM77	RL07	RL27	RL37	RL67	RL77	
Side guiding Seitenführung Guidage latéral		Cord guide Seilführung <i>Guidage par câbles</i>	RS01 RS05	RS11 RS15	RS21 RS26	RM01 RM06 RM07	RM11 RM16 RM17	RM21 RM26 RM27	RM31 RM36	RM41 RM46 RM47	RM61 RM66 RM67	RM51 RM56 RM57	RM71 RM76 RM77	RL01 RL06 RL07	RL21 RL26 RL27	RL31 RL36 RL37	RL61 RL66 RL67	RL71 RL76 RL77
		Side profile Profilführung <i>Guidage par coulisse</i>			RS21 RS26			RM21 RM26 RM27	RM31 RM36						RL21 RL26 RL27	RL31 RL36 RL37		
Others Sonstiges Divers		Coupling Koppeln <i>Jumelage</i>				RM01 RM06 RM07	RM11 RM16 RM17	RM21 RM26 RM27	RM31 RM36	RM41 RM46 RM47	RM61 RM66 RM67	RM51 RM56 RM57	RM71 RM76 RM77	RL01 RL06 RL07	RL21 RL26 RL27	RL31 RL36 RL37	RL61 RL66 RL67	RL71 RL76 RL77